



#### 4.5 Entering To The Programming Mode, Changing and Saving Parameter



**EMKO**  
Temperature Controller  
ESM-3712-HC 77x35 DIN Size



**ESM-3712-HC(SET + ALARM)**  
77 x 35 DIN Size  
Digital, ON / OFF Temperature Controller

- 3 Digits display
- PTC input or NTC input or J Type Thermocouple input or K Type Thermocouple input or 2-wire PT-100 input or 2-wire PT-1000 input (It must be determined in order)
- Temperature control output and alarm output
- Process and alarm set values boundaries
- Selectable heating or cooling function
- Adjustable temperature offset value
- Relay or SSR driver output
- Operation selection of compressor operates continuously, stops or operates periodically in case of probe defect
- Compressor protection times
- Password protection for programming section

Instruction Manual, ENG ESM-3712-HC 01 V03 07/13

#### 1.Preface


ESM-3712-HC series temperature controllers are designed for measuring and controlling temperature. They can be used in many applications with their On / Off control form, heating and cooling control form and easy-use properties. Some application fields which they are used are below:

Application Fields	Applications
Glass	Heating
Food	Baking Ovens
Plastic	Incubators
Petro-Chemistry	Storages
Textile, Automotive	Air Conditioning
Machine Production Industries	Etc...
Etc...	


#### 1.1 Operating Conditions

- Operating Temperature : 0 to 50 °C
- Max. Operating Humidity : 90% Rh (non-condensing)
- Altitude : Up to 2000 m.
- Forbidden Conditions: Corrosive atmosphere, Explosive atmosphere, Home applications (The unit is only for industrial applications)

#### 1.2 General Specifications



#### 5. Failure Messages in ESM-3712-HC Temperature Controller



Probe defect in analogue inputs. Sensor connection is wrong or there is no sensor connection.

#### 6. Ordering Information

Ordering Information	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
ESM-3712-HC (77x35 DIN Size)																										

A	Supply Voltage	
1	100...240V ~ (-%15;+%10) 50/60Hz	
2	24V ~ (-%15;+%10) 50/60Hz 24V ~ (-%15;+%10)	
9	Customer	
BC	Input Type	Scale(°C)
05	J, Fe CuNi IEC584.1(ITS90)	0°C 800°C
10	K, NiCr Ni IEC584.1(ITS90)	0°C 999°C
11	PT 100, IEC751(ITS90)	-50°C 400°C
09	PT 100, IEC751(ITS90)	-19.9°C 99.9°C
12	PTC (Note-1)	-50°C 150°C
15	PTC (Note-1)	-19.9°C 99.9°C
14	PT 1000, IEC751(ITS90)	-50°C 400°C
13	PT 1000, IEC751(ITS90)	-19.9°C 99.9°C
18	NTC (Note-1)	-50°C 100°C
19	NTC (Note-1)	-19.9°C 99.9°C

All order information of ESM-3712-HC Temperature Controller are given on the table at left. User may form appropriate device configuration from information and codes that at the table and convert it to the ordering codes.

Firstly, supply voltage then other specifications must be determined. Please fill the order code blanks according to your needs.

Please contact us, if your needs are out of the standards.

~ Symbol means Vac,  
- Symbol means Vdc,  
~ Symbol means Vac/dc

E	FG	Outputs
1	01	Process Out Relay Output (10A@250V ~ at resistive load, 1NO)
2	02	Alarm Out Relay Output (5A@250V ~ at resistive load, 1NO)
3	03	Process Out SSR Driver Output (Max. 24mA, 16V ~)
4	04	Alarm Out SSR Driver Output (Max. 24mA, 16V ~)
V	Temp. Sensor which is given with ESM 3712 HC	
0	None	
1	PTC-M6L40.K1.5 (PTC Air Probe with 1.5 m silicon cable)	
2	PTCS-M6L30.K1.5.1/8" (PTC Liquid Probe with 1.5 m silicon cable)	
3	NTC-M5L20.K1.5 (NTC Probe, thermoplastic moulded with 1.5 m cable for cooling application)	
4	NTC-M6L50.K1.5 (NTC Probe, stainless steel housing with 1.5 m cable for cooling application)	
9	Customer	

#### 7. Specifications

<b>Device Type</b>	: Temperature Controller
<b>Housing&amp;Mounting</b>	: 77 mm x 35 mm x 62.5 mm plastic housing for panel Mounting. Panel cut-out is 71 x 29 mm.
<b>Protection Class</b>	: NEMA 4X (IP65 at front , IP20 at rear).
<b>Weight</b>	: Approximately 0.20 Kg.
<b>Environmental Ratings</b>	: Standard, indoor at an altitude of less than 2000 meters with none condensing humidity.
<b>Storage / Operating Temperature</b>	: -40 °C to +85 °C / 0 °C to +50 °C
<b>Storage / Operating Humidity</b>	: 90 % max. (None condensing)
<b>Installation</b>	: Fixed installation
<b>Overvoltage Category</b>	: II.
<b>Pollution Degree</b>	: II, office or workplace, none conductive pollution
<b>Operating Conditions</b>	: Continuous
<b>Supply Voltage and Power</b>	: 100-240 V ~ (-%15;+%10) 50/60 Hz. 2VA 24V ~ (-%15;+%10) 50/60 Hz. 2VA 24V ~ (-%15;+%10) 2W
<b>Temperature Sensor Inputs</b>	: NTC, PTC, TC, RTD
<b>NTC Input Type</b>	: NTC (10 k @.25 °C )
<b>PTC Input Type</b>	: PTC (1000 @.25 °C )
<b>Thermocouple Input Types</b>	: J, K (IECS84.1)(ITS90)
<b>Thermoresistance Input Type</b>	: PT-100, PT-1000 (IEC751)(ITS90)
<b>Accuracy</b>	: ±1% of full scale for thermocouple and thermoresistance
<b>Cold Junction Compensation</b>	: Automatically ± 0.1°C/1°C.
<b>Sensor Break Protection</b>	: Upscale
<b>Sampling Cycle</b>	: 3 samples per second
<b>Control Form</b>	: ON / OFF
<b>Relay Output</b>	: Resistive Load 10 A@250 V ~ (Electrical Life : 100.000 operation (Full Load)
<b>Optional SSR Output</b>	: Maximum 24 mA, Maximum 16 V ~
<b>Display</b>	: 14 mm Red 3 digits LED Display
<b>Leds</b>	: SV (Green), OUT (Red), P(Red), Alarm(Red) 3 mm
<b>Approvals</b>	: GOST-R, CE

#### 8. Other Informations

**Manufacturer Information:**  
Emko Elektronik Sanayi ve Ticaret A.Ş.  
Demirtaş Organize Sanayi Bölgesi Karanfil Sk. No:6 16369 BURSA / TURKEY  
Tel : +90 224 261 1900  
Fax : +90 224 261 1912

**Repair and maintenance service information:**  
Emko Elektronik Sanayi ve Ticaret A.Ş.  
Demirtaş Organize Sanayi Bölgesi Karanfil Sk. No:6 16369 BURSA / TURKEY  
Tel : +90 224 261 1900  
Fax : +90 224 261 1912

**EMKO** Thank you very much for your preference to use Emko Elektronik products, please visit our [www.emkoelektronik.com.tr](http://www.emkoelektronik.com.tr) Technology Partner web page to download user manual.

#### 1.3 Installation

Before beginning installation of this product, please read the instruction manual and warnings below carefully.

- In package ,
- One piece unit
- Two pieces mounting clamps
- One piece instruction manual

A visual inspection of this product for possible damage occurred during shipment is recommended before installation. It is your responsibility to ensure that qualified mechanical and electrical technicians install this product.

If there is danger of serious accident resulting from a failure or defect in this unit, power off the system and separate the electrical connection of the device from the system.

The unit is normally supplied without a power supply switch or a fuse. Use power switch and fuse as required.

Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.

Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

Never attempt to disassemble, modify or repair this unit. Tampering with the unit may result in malfunction, electric shock or fire.

Do not use the unit in combustible or explosive gaseous atmospheres.

During the equipment is putted in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you must be careful.

Montage of the product on a system must be done with it's fixing clamps. Do not do the montage of the device with inappropriate fixing clamp. Be sure that device will not fall while doing the montage.

It is your responsibility if this equipment is used in a manner not specified in this instruction manual.


#### 1.4 Warranty

EMKO Elektronik warrants that the equipment delivered is free from defects in material and workmanship. This warranty is provided for a period of two years. The warranty period starts from the delivery date. This warranty is in force if duty and responsibilities which are determined in warranty document and instruction manual performs by the customer completely.


#### 1.5 Maintenance

Repairs should only be performed by trained and specialized personnel. Cut power to the device before accessing internal parts. Do not clean the case with hydrocarbon-based solvents (Petrol, Trichlorethylene etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.


#### 2. General Description



#### 2.1 Front View and Dimensions of ESM-3712-HC Temperature Controller




#### 2.2 Panel Cut-Out






### 2.3 Panel Mounting



1-Before mounting the device in your panel, make sure that the cut-out is of the right size.  
2-Insert the device through the cut-out. If the mounting clamps are on the unit, put out them before inserting the unit to the panel.


### 2.4 Installation Fixing Clamp



The unit is designed for panel mounting.  
1-Insert the unit in the panel cut-out from the front side.  
2- Insert the mounting clamps to the holes that located left and right sides of the device and make the unit completely immobile within the panel

Montage of the unit to a system must be done with it's own fixing clamps. Do not do the montage of the device with inappropriate fixing clamps. Be sure that device will not fall while doing the montage.

### 2.5 Removing from the Panel




Loosen the screws  
1-Pull mounting clamps from left and right fixing sockets.  
2-Pull the unit through the front side of the panel

Before starting to remove the unit from panel, power off the unit and the related system.

### 3.2 Temperature Sensor Input Connection

#### 3.2.1 TC (Thermocouple) Connection




Connect the wires with the polarity as shown in the figure left.

Always use compensation wire corresponding to the thermocouple used. If present, the shield must be connected to a proper ground.

Input resistance is greater than 10M


#### 3.2.2 PTC and NTC Connection



Input resistance is greater than 10M


Pay attention to the cable colours of PTC probe while doing the PTC probe connection.

#### 3.2.3 PT-100 and PT-1000 Connection




Input resistance is greater than 10M

### 3. Electrical Wiring Diagram



#### 3.1 Supply Voltage Input Connection of the Device




Make sure that the power supply voltage is same indicated on the instrument. Switch on the power supply only after that all the electrical connection have been completed. Supply voltage range must be determined in order. While installing the unit, supply voltage range must be controlled and appropriate supply voltage must be applied to the unit. Controlling prevents damages in unit and system and possible accidents as a result of incorrect supply voltage.

There is no power supply switch or fuse on the device. So a power supply switch and a fuse must be added to the supply voltage input. Power supply switch and fuse must be put to a place where user can reach easily. Power supply switch must be two poled for separating phase and neutral. On/Off condition of power supply switch is very important in electrical connection. On/Off condition of power supply switch must be signed for preventing the wrong connection.

External fuse must be on phase connection in ~ supply input. External fuse must be on (+) line connection in ~ supply input. The instrument is protected with an internal fuse (Please refer to Note-1 for information). In case of failure it is suggested to return the instrument to the manufacturer for repair.


### 4. Front Panel Definition and Accessing to the Menus



Note-1: If increment or decrement button is pressed for 5 seconds continuously, increment and decrement number become 10, if increment or decrement button is pressed for 10 seconds continuously, increment and decrement number become 100.


#### 4.1 Observation of Software Revision on the Displays

When power is first applied to the temperature controller, software revision number is shown on the displays.



If there is an unexpected situation while opening the device, power off the device and inform a qualified personnel.

### 4.2 Changing and Saving Set Value




SET value is can be adjusted from minimum set value parameter [SUL] to maximum set value parameter [SUH], Which can be accessed from programming parameters.

If no operation is performed in Set value mode for 20 seconds, device turns to main operation screen automatically.

### 4.3 Program Parameters

- HSE** Hysteresis Parameter for Output (Default = 1)  
1 to 100 °C for TC Type Devices, 1 to 100 °C for PT-100 (-50°C, 400°C) and PT-1000 (-50°C, 400°C), 0.1 to 10.0 °C for PT-100 (-19.9°C, 99.9°C) and PT-1000 (-19.9°C, 99.9°C), 1 to 20 °C for PTC (-50°C, 150°C) and NTC (-50°C, 100°C), 0.1 to 10.0 °C for PTC (-19.9°C, 99.9°C) and NTC (-19.9°C, 99.9°C)
- SUL** Minimum Set Value Parameter (Default = Minimum value of device scale)  
Set value can not be lower than this value. This parameter value can be adjusted from minimum value of device scale to maximum set value parameter [SUH]
- SUH** Maximum Set Value Parameter (Default = Maximum value of device scale)  
Set value can not be greater than this value. This parameter value can be adjusted from minimum set value [SUL] to maximum value of the device scale
- OFF** Process Offset Parameter (Default = 0)  
-100 to 100 °C for TC Type Devices, -100 to 100 °C for PT-100 (-50°C, 400°C) and PT-1000 (-50°C, 400°C), -10.0 to 10.0 °C for PT-100 (-19.9°C, 99.9°C) and PT-1000 (-19.9°C, 99.9°C), -20 to 20 °C for PTC (-50°C, 150°C) and NTC (-50°C, 100°C), -10.0 to 10.0 °C for PTC (-19.9°C, 99.9°C) and NTC (-19.9°C, 99.9°C)
- ALS** Alarm Type Selection Parameter  
0 Sensor Failure Alarm  
1 Process High Alarm  
2 Process Low Alarm  
3 Deviation High Alarm  
4 Deviation Low Alarm  
5 Deviation Band Alarm  
6 Deviation Range Alarm
- ALL** Alarm Set Value Low Limit Parameter  
Alarm set value can not be lower than this value. This parameter value can be adjusted from, minimum process set value parameter to alarm set value high limit parameter value.
- AUL** Alarm Set Value High Limit Parameter  
Alarm set value can not be greater than this value. This parameter value can be adjusted from alarm set value low limit parameter value to maximum process set value parameter
- POn** Alarm On Delay Time Parameter  
It can be adjusted from 0 to 99 minutes.
- POF** Alarm Off Delay Time Parameter  
It can be adjusted from 0 to 99 minutes. When this parameter is 99, if increment button is pressed, [LCH] is observed and alarm latching output is selected. To make the alarm latching output passive, decrement button must be pressed in main operation screen.
- APD** Alarm Delay Parameter After Power On  
This parameter defines the delay for the alarm is being active after power on. It can be adjusted from 0 to 99 minutes.

### 4.4 Easy Access Diagram Of Programming Mode Parameters



If no operation is performed in Programming mode for 20 seconds, device turns to main operation screen automatically.

[POs], [SPd], [Std], [P.dF], [POn] and [POF] parameters are observed if Operating type is selected "Cooling". If operating type is selected "Heating" beginning of the parameters list is shown.